



Integrative Manual for the Installer

version 1.06

W200 MULTI (multiprogram)



PROGRAM SELECTION

The "MULTI" instruments do not have any selected program but they can be set by the installer with different modes of operation:

- BASE
- LOAD
- UNLOAD
- 3 PRODUCTS
- 6 PRODUCTS
- 14 PRODUCTS

Upon the instrument switching on, the display shows the message **MULTI**, to select the required program proceed as follows.

Turn off the instrument, turn it on again holding down the **[ESC]** key until the display shows **PrDd**, confirm and select the required program using the arrow keys:

- **bASe**: basic program, management of setpoints only.
- **rEUEr**: to be used when on a loaded weighing system corresponds a situation of unloaded cells and vice versa (the weight increases while in reality on the system it is decreasing).
- **r rP**: remote display program with setpoints.
- **LOAD**: monoprodukt loading program.
- **UnLOAD**: monoprodukt unloading program.
- **3PrDd**: 3 products batching.
- **6PrDd**: 6 products batching (**WARNING: this program requires the RELE6PROD external relay module**).
- **14PrDd**: 14 products batching (**WARNING: this program requires both the RELE6PROD external relay module and the RELE14PROD external relay module**).



By confirming the required program, the system's variables are set with default values.



After each operation the display shows **dOnE**, press **[ENTER]** to continue.

By pressing **[ESC]** you exit without selecting any program. The choice of program may also be repeated at a later time and several times, repeating the above procedure.

After confirming the choice of the program (except *LEGAL* and *LEGAL*), the user must choose its approval state among the following possible choices:



NOTLEGAL: not approved program (for internal use only)

LEGAL: approved program, single division (Dir. 2009/23/EC, art. 1)*

LEGAL: approved program, multi-interval (Dir. 2009/23/EC, art. 1)*

LEGAL: approved program, multiple range (Dir. 2009/23/EC, art. 1)*

*) CE- **M** APPROVED INSTRUMENTS EN45501-2009/23/EC-OIML R76:2006:
contact the support service to request the correct procedures for approval,
indicating mandatory hardware code and serial number.

After selecting the desired program, refer to the specific program manual for setting and instrument commissioning:

INSTALLATION AND USER MANUALS

- W200 BASE - W200 LOAD - W200 UNLOAD - W200 3/6/14 PRODUCTS	- W200 BASE approved - W200 LOAD approved - W200 UNLOAD approved - W200 3/6/14 PRODUCTS approved
---	---